

Rev.	Description	Date	Designer	Approved	Ref.
A	Utgitt for marked	01.04.2025	THB	Bak	

Brukerveiledning for
Stabilisator for 3-punkt
Art.nr 27018

Beskrivelse

Stabilisator for 3-punkt art 27018 er utstyr designet for bruk på Tokvam AT 500 R. Det er egnet for bæremaskiner beskrevet i hovedproduktets brukerveiledning.

Vekt:

102.87 kg.

CE merking garanti

Modifisering/ endringer og ombygginger utover hva som er beskrevet i denne brukermanualen medfører at CE merkingen bortfaller. Det samme gjelder opprinnelig produsentansvar og garanti.

Tokvam AS står ikke ansvarlig for eventuelle skader som oppstår som konsekvens av at utstyret brukes utenom tiltenkte bruksområde beskrevet i brukerveiledningen.

Tokvam driver kontinuerlig produktutvikling, og forbeholder oss retten til å endre data og spesifikasjoner på nye maskiner uten forutgående varsel.


!Sikkerhet

-Det er førerens ansvar å sørge for at redskapen ikke medfører en sikkerhetsrisiko for seg selv eller andre.

-Vær oppmerksom på bredde, høyde og vekt ved montering av tilleggsutstyr. Sikt og kjøregenskaper kan endres!

Vedlikehold

Ingen



Users manual for
Stabilizer for 3-point hitch
Art.no 27018

Description

Stabilizer for 3-point hitch art 27018 is equipment designed for use on Tokvam AT 500 R. It is designated for carrier vehicles described in primary products user's manual.

Weight:

102.87 kg.

CE certified warranty

Any modification, change or conversion of this product will discontinue warranty. This also applies to Tokvam's responsibility and warranty.

Tokvam AS cannot be held responsible for any harm that may occur from use that is not described in this user's manual.

Tokvam AS is continuously improving our products, and we reserve the rights to make changes to any specifications of new products without further notice.


!Safety

-It is the driver's responsibility to ensure that the machine is not used or handled incorrectly.


-Pay attention to width, height and weight when additional equipment is attached, this can change handling and visibility!

Maintainance

None



Deleliste/Parts list
Art.nr/no 27018



14	2	27363	Reduksjonsbøsning toppstag kat.3/2 Ø32/Ø25,7	Reduction bushing top link cat.3/2 Ø32/Ø25,7
13	4	27341	Sekskantskrue M24x140 D	Hexagon bolt M24x140 Part. thread
12	2	27340	Toppstag øye/øye M36 kat.2/2, 56-78	Toplink eye/eye M36 kat.2/2, 56-78
11	1	27335	Toppstagfeste for stabilisator	Top strut attachment for stabilizer
10	1	27323	Arm for trekkrok	Arm for trailer hitch
9	1	27318	Bæreramme for støtte på tilhengerkrok	Carrier frame for support at trailer hitch
8	1	27021	Nedre brakett	Lower bracket
7	2	19379	Redskapsbolt kat3 Ø32x119	Bolt kat3 Ø32x119 mm
6	2	16257	Toppstagbolt 25,4X136mm kat.2	Top linkage bolt 25,4X136mm cat.2
5	1	15969	Toppstag 1"x1" 535-815mm	Toplink 1"x1" 535-815mm
4	4	15780	Toppstagbolt 25.4x77mm kat.2	Top linkage Bolt 25.4x77mm Cat.2
3	4	13661	Låsemutter M24	Lock nut M24
2	3	11875	Toppstagbolt 25,4x99mm kat.2	Top linkage bolt 25,4x99mm cat.2
1	12	10206	Traktor ringsplint 10 mm	Linch pin 10 mm
Pos.	Qty.	Art.no.	Description	EngDescription

Montering på AT 500 R:

1. Monter (8) på trekkarmfestene på AT 500 R med festemateriell (13) + (3)
2. Monter (9) til (8) med (2) + (1) og monter så (10) som låses med (1)
3. Monter (12) på (8) med (4) + (1) og legg disse midlertidig bakover på maskinen
4. (11) monteres i toppstagfestet på traktoren med to bolter. Velg mellom (7) + (1) eller (6) + (14) + (1) etter hva som passer din traktor
5. Rygg traktor inntil maskin og fest (10) i tilhengerkroken og lås denne.
6. Fest traktorens trekkarmer til maskinen og monter PTO-aksel
7. Monter (5) mellom maskin og (11)
8. Løft maskinen opp til ønsket arbeidshøyde (horisontal og rett PTO-aksel) og juster (5) til maskinen står rett
9. Ta så de to (12) og juster disse til å passe mot (11) om monter med (4) + (1)
10. Senk og avlast trekkarmene slik at maskina henger i toppstagfestet
11. Monter hydraulikkslanger ogelektrisk kabel, og maskinen er klar til drift

Assembly on AT 500 R:

1. Assemble (8) to the drawbar mounts of the AT 500 R using (13) + (3)
2. Mount (9) to (8) with (2) + (1). Then mount (10) and lock it using (1)
3. Mount (12) to (8) using (4) + (1) and lay them temporarily backwards on the machine
4. Mount (11) to the topplink attachment of the tractor using two bolts. Choose between (7) + (1) or (6) + (14) + (1) according to what fits your tractor
5. Back the tractor against the machine and fix (10) to the trailer hook and lock it
6. Fix the tractor drawbars to the machine and attach the PTO shaft
7. Assemble (5) between the machine and (11)
8. Lift the machine to the desired height (horizontal PTO shaft) and adjust (5) until the machine is level
9. Take the two (12) and adjust them to fit (11) and assemble using (4) + (1)
10. Lower the drawbars to relieve them. The machine is now carried by the topplink attachment
11. Attach hydraulic hoses and electric cable, and the machine is ready for use

